






# Installation Instructions






1. Remove the yellow tape.








2. Insert the cartridge into corresponding slot and ensure it to be flush with other cartridges.



3. Pop-up window may appear with "Non-HP" notice after installation. (On some printers)



4. The pop-up window "Low on ink" and the low ink column remind you to prepare a replacement cartridge. Or you may judge remaining ink volume by the glittering Paper Feed button and volume indicator as well as the glittering Ink indicator.



5. Replace the cartridge when "Ink Cartridges Depleted" and "Use Black (or Color) Ink Only?" pop up and the ink column is empty. Or you may judge and replace by empty remaining ink volume and Glittering Ink indicator.

**Note:**

1. Reload the cartridge when there is non-recognition.
2. Clean the printhead when color mixture comes out.
3. Do not first load the cartridge in a new printer.